

Maintenance Schedules

2018 Lincoln MKT	
Driving Condition:	Normal Condition
Cylinders:	6

Recommended maintenance for your vehicle

This vehicle is equipped with Intelligent Oil Life Monitor (IOLM). Based on driving condition, the IOLM will display a message when your vehicle needs an oil change. Every time the display reads 'Oil Change Required', the following maintenance is recommended.



- Change engine oil and filter.
- Inspect brake pads, rotors, hoses and parking brake.
- Inspect engine cooling system strength and hoses.
- Inspect exhaust system and heat shields.
- Inspect half-shaft boots.
- Inspect rear axle and U-joints.
- Inspect steering linkage, ball joints, suspension, tie-rod ends, driveshaft and U-joints.
- Inspect the automatic transmission fluid level (if equipped with a dipstick). Consult your dealer for requirements.
- Inspect the tires, tire wear and measure the tread depth.
- Inspect the wheels and related components for abnormal noise, wear, looseness or drag.
- Perform multi-point inspection.
- Rotate the tires.

Mileage	20K	30K	40K	60K	80K	90K	100K	120K	140K	150K
Change automatic transmission fluid.										X
Change engine coolant.							X			X
Inspect accessory drive belt(s).							X			
Replace accessory drive belt(s).										X
Replace cabin air filter.	X		X	X	X		X	X	X	

Mileage	20K	30K	40K	60K	80K	90K	100K	120K	140K	150K
Replace engine air filter(s).		X		X		X		X		X
Replace spark plugs.							X			

Following the recommended Maintenance Schedule is the best way to keep your vehicles running right - it provides exactly what your vehicle needs, when it needs it. Visit Genuine Ford and Lincoln Mercury Parts & Service website for additional vehicle maintenance information.

[New Search](#)

[Print](#)